

## **SeeYA Optics Module Preliminary Specification**

**Model name:**

## Revision

Version	Date	Description
V0.0	2021.07.13	Initial release

SeeYa Only

## Contents

<b>1</b>	<b>General Description.....</b>	<b>4</b>
<b>2</b>	<b>Technical Specification .....</b>	<b>4</b>
<b>3</b>	<b>Module Diagram.....</b>	<b>7</b>
<b>4</b>	<b>Reliability .....</b>	<b>8</b>
<b>5</b>	<b>Handling Precautions.....</b>	<b>9</b>
	Mounting Method .....	9
	Caution of Handling and Cleaning .....	9
	Caution of Against Static Charge .....	9
	Packing 9	
	Caution for Operation .....	9
	Storage 10	
	Safety Precautions.....	10
	Precautions before use.....	10
<b>6</b>	<b>Packing.....</b>	<b>11</b>

## 1 General Description

---

This module consists of two displays, optical lens, mechanical parts. Display source is the 1.03 inch MicroOLED with the Highest Luminance 1800 nits and rendered resolution of 2560\*2560.

- Display resolution: 2560 x 2560
- Field of View: 90° at 0D
- Diopter adjustable from 0D to -5D

## 2 Technical Specification

---

Parameter	Specification
<b>Optical Data:</b>	
Diopter Range	0 D ~ 5 D
FOV (inscribed circle)	90 degree
Eyebox	8 mm
Eye Relief	12 mm
TV Distortion	12 %
Lateral Chromatic Aberration	6.2 um
Longitudinal Chromatic Aberration	40.2 um
MTF	MTF > 0.1 @70lp/mm (whole field)
Light Efficiency	8 %
<b>Physical Data:</b>	
Lens Structure	5G
Lens Weight	< 25 g
Module Weight (include lens)	< 64 g
Module Length (total track length)	17 mm
Diameter (lens only max.)	30 mm

\* The parameters above are under 0D conditions in multi-diopter module.

**Note1:** FOV

FOV of optical module is the circular field of view for the visual image as the schematic shown.




Fig. 1

**Note2:** Eyebox and Eye Relief

Eyebox is the pupil range where the full virtual image could be caught. Eye relief is the distance between the optical lens to the pupil.




Fig. 2

**Note3:** TV Distortion

$$TV \text{ Distortion} = \text{Max} \left( \frac{\Delta H_{\text{horizontal}}}{H_{\text{horizontal}}}, \frac{\Delta H_{\text{vertical}}}{H_{\text{vertical}}} \right) \times 100\%$$

The test area is inside the circle with 45 degrees FOV, and aspect ratio is 16:9.




Fig. 3

**Note4:** MTF

MTF formula:  $M = \frac{(L_{\max} - L_{\min})}{(L_{\max} + L_{\min})}$ ,  $L_{\max}$  and  $L_{\min}$  is the brightness of the jointed black and white line.




Fig. 4

### 3 Module Diagram

